

Emergency Lights

1. Next to Breaker Switch
2. Need key to rock switch

These need to be tested once a year by a professional.

If the green light is blinking it is probably due to a fault.

These have 2 power supplies. When the professional does the test they kill the permanent power supply to see if the battery is still working. The battery should last a minimum of 3 hours.

Revision #2

Created 4 December 2024 08:40:08 by Cittadhammo Bhikkhu

Updated 25 March 2025 09:47:16 by Ruciro Bhikkhu