

# Light sensors with timer

## **Pendant light outside the main sala porch and lights in the sala lobby (shoe area) (2 X LED, 2 X pendant lights)**

These lights are controlled by two sensors:

1) An analogue timer (this takes priority; so the lights can be automatically programmed to turn off during the middle period of the night).

2) Light sensors.

Lights gets automatically turned on/off via a light sensor that is activated by a timer (now set at 4 am - 10 pm). Since it is analogue, it will need resetting if we have a power cut.

For instance, light sensor automatically turns on / turns off the pendant light outside the main sala porch and lights (2 X LED, 2 X pendant lights) in the lobby when it detects darkness / light outside surrounding area.

### Locations

of the light sensors: Adjacent to the external window of porch and sala lobby only.



of the timer: sala storage room (beside the fuse box)



# All external lights between eastern side entrance of sala and workshop

Locations

of the light sensor: next to dana entrance



of the timer: kitchen attic store



There is also a timer in the workshop.

---

Revision #12

Created 25 November 2024 22:48:48 by Sr Tejasa

Updated 25 March 2025 09:47:16 by Ruciro Bhikkhu