

Visual cheatsheet



Dishwasher operation

- switch on the isolator (red and yellow, on the wall)
- touch the start button to load water in the tank
- wait until the green wheel is complete (loading and warming up water)
- select QUICK cycle (with the hood open) by pressing the "clock" icon and the up/down/select icons:

- ☐ quick (recommended)
- ☐ standard (default)
- ☐ intensive (for oily pots and pans)

- prepare the kitchenware for washing:
 - o remove food from plates, rinse, load on basket
 - o load the basket in the machine
 - o lower the hood: the selected cycle starts
 - o the machine beeps when the cycle is finished
(wait 30", until the ventilation system will be installed)
 - o open the hood
 - o slide forward the cleaned basket on the line, to air dry
- repeat (°)
- All concave surfaces must face down
- Be careful not to let cutlery drop inside the machine
(only use baskets with fine mesh)
- Carry out the relevant cleaning operations at the end of the working day
(please turn this sheet)

Dishwasher daily cleaning

At the end of the working day:

- drain the tank (press and hold 5" the start button); the machine will turn off
- switch off isolator
- remove the grille
- check lower sprayers, remove and clean if needed
- remove filters + blue filter in the tank, clean
- clean the inside surfaces of the machine with a soft cloth and detergent, to remove all debris
- replace filters, blue filter, sprayers, grille (on lower notches)
- empty and clean the outer debris basket
- leave machine open to dry

- clean the grease trap

Dishwasher weekly cleaning (Sundays)

At the end of the working day:

- drain the tank (press and hold 5" the start button); the machine will turn off
- switch off isolator
- remove down and up sprayers, wash in soapy water, rinse
- remove filters + blue filter in the tank, wash in soapy water, rinse
- replace filters, blue filter, sprayers
- empty and clean outer food basket
- leave machine open to dry
- clean the grease trap

Dishwasher monthly cleaning (Kitchen Cleanup days)

At the end of the working day:

- do NOT drain the machine
- put one hygiene tablet inside the machine (caution: irritant – use gloves)
- select and run hygiene cycle (20 min)
- check salt level, top up if necessary
- drain the machine
- check detergent/rinse levels (5 l cans), replace can if necessary

(keep pierced caps)

- leave the hood open at the end of cycle
- turn off the isolator

Revision #3

Created 24 March 2025 08:23:41 by Site Manager (Eleonora)

Updated 24 March 2025 09:05:09 by Site Manager (Eleonora)